



## Информация за продукт: Cleaning concentrate for developing machines

Описание на продукта: Cleaning concentrate for developing machines

Област на използване: Automatic plate processors

Особености: density: 2,1 g/cm<sup>3</sup>  
colour: white  
pH-value: 1,2 (10 g/l)

Начин на употреба:

- dissolve the concentrate in approx. 10 litres of water
- fill the solution in the tank
- let the automatic plate processor operate for approx. 30 minutes
- drain off the solution
- tank walls and rollers have to be cleaned with a viscose sponge resp. a brush
- finally, fill the tank with pure water and let the automatic plate processor operate for another 5 minutes
- the rinsing process must be repeated twice

Бележки: UN 2967, class 8, packaging group III, ADR

Бройка/количество: 12 x 1 kg in a carton

Обяснителна бележка: **Attention!** The cleaning concentrate solution must not remain in the automatic plate processor for a longer time, as metal parts might be affected.